

● **Compatível com as principais marcas de notebooks:**

<b>S1</b>	<b>Compaq</b> <b>Evo:</b> N100v, N1015V, N1050v <b>Presario:</b> 900 series, 1500 series, N1050v
<b>S5</b>	<b>Presario:</b> 1110, 1115, 1120, 2100 series, 2500 series, 3005, 3015, 3017, 3019, 3020, 3080
<b>S10</b>	<b>Dell</b> <b>Inspiron:</b> 2500, 2600, 2650, 3700, 3800, 4000, 4150, 5000, 7500, 8000, 8100 <b>Latitude:</b> X200 (Power Only), C400, C410, C500. C510, C600, C610, C640, C800, CP, CPi, CPt, CPx, CS/CSx, LM
<b>S5</b> <b>S11</b>	<b>Fujitsu</b> <b>LifeBook:</b> C1020 <b>LifeBook:</b> 270Dx, 280Dx, 420D, 435Dx. 500, 520D, 520T, 531T, 535Tx, 555T, 565Tx, 585Tx, 585Tx1, 635T, 635Tx, 635Tx1, 655Tx, 656Tx, 675Tx, 690Tx, 735Dx, 755Tx, 756Dx, 765Tx, 770Tx, 790Tx, 985Tx, 990Tx2, A4170, B112. B142, B2, B2130, B2131, B2175, B-2545, B-2562, B-2566, B2610, B2620, B2630, B3010D, B3020, B3020D, C340, C350, C352, C353, C360, C-4120, C-4235, C-5130, C-5235, C-6177, C-6320, C-6330, C-6525, C-6535, C-6537, C-6547, C-6556, C-6557, C-6577, C-6581, C-6591, C-6611, C-6631, C-6651, C-7631, C-7651, C7661, E2010, E330, E340, E342, E350, E351, E335, E360, E362, E380, E-5140, E-5320, E-5520, E-6150, E-6520, E-6530, E-6540, E-6541, E-6550, E-6555, E-6556, E-6557, E-6570, E-6571, E-6575, E-6595, L440, L470, P-1000, P-1032, P-1035, P-1110, P-1120, P-2000, P-2040, P-2046, P-2110, P-2120, P-5010, P-5010D, P-5020, P-7010, P-7010D, S-2010, S-2020, S-4510, S-4546, S-4572, S-5582, S6010, S6110, S6120, S6120D, S6210, S6220, S6231, T3010, T3010D <b>Stylistic:</b> CT2020, 3400, 3500, ST4110, ST4110P, ST4120, ST4120P, ST4121, ST5010, ST5010D, ST5011, ST5011D, ST5020, ST5020D, ST5021, ST5022 <b>Celsius:</b> Mobile H <b>Stylistic LT:</b> C-500, P-600
<b>S5</b>	<b>Hp</b> <b>Business Notebooks:</b> NX9000, NX9005, NX9008, NX9010 <b>Pavilion:</b> ze4000, ze4400 series, ze4500 series, ze4600, ze4601, ze4605, ze4610, ze4615, ze4630, ze4631, ze4700, ze4715, ze4717, ze4725, ze4800, ze4805us, ze5000 series, ze5200 series, ze5300 series, ze5400 series, ze5500 series, ze5600 series, ze5700 series, zv5434RS
<b>S4</b>	<b>IBM</b> <b>ThinkPad:</b> 600E, 600X, 770E, 770ED, 770X, 770Z, A series, R series, T series, X series, Transnote
<b>S4</b> <b>S11</b>	<b>Panasonic</b> <b>Toughbook:</b> CF29, CF-50, CF-73, CF-R1, CF-T1, CF-T2 <b>Toughbook:</b> CF01, CF11, CF17, CF170, CF270, CF370, CF380, CF25, CF27. CF28, CF33, CF34, CF35, CF37, CF41, CF45, CF47, CF48, CF61 CF62, CF63, CF71, CF72, CF-M34, CF-V25, CF-V41
<b>S11</b>	<b>Sony</b> <b>Picturebook:</b> C1X <b>Vaio:</b> B100B, C1MHP, GR100, GR100K, GR114EK, GR114MK, GR114SK, GR150K, GR170K, GR200, GR200K, GR200P, GR214CP, GR214EP, GR214MP, GR215MP, GR215SP, GR250, GR250K, GR250P, GR270, GR270K, GR270P, GR290, GR290K, GR290P, GR300, GR314MP, GR315MP, GR370, GR390, GR414SP, S260, S360, S150, S150P, S170, S270, SR11K, SR17, SR17K, SR1K, SR21K, SR5K, SR7K, SR9G, SRX41P, SRX51P, SRX51PA, SRX51PB, T140 series, T150 series, T160 series, T250 series, T270P/L, T340P/L, T350 series, T360P/L, T370P/L, TR1A, TR1AP, TR2A, TR2AP1, TR2AP3, TR3AP1, TR3AP2, TR1, TR2, TR3, TR5GP, V505A, V505AC, V505BXP, V505D, V505DC1, V505DC11, V505DC1P7, V505DX, V505DXP, V505EXP, V505EC, V505ECP1, V505DC1PF, V505DC1P2, V505DX, V505DXP, VX71P, X505, X505ZPKIT, X505ZPKIT2, Z1, Z1A, Z1AP1, Z1AP2, Z1AP3, Z1M, Z1R5P, Z1RA, Z1RAP1, Z1RAP2, Z1RAP3, Z1SP, Z1VAP1, Z1WAMP1, Z1WAP, Z11ZAP1, Z505AX, Z505AXP
<b>S12</b>	<b>Vaio:</b> 81, 705, 707, 717, 719, 729, 731, 735, 748, 800, 808, 812, 818, 838, C1XW, F series, F150, F160, F180, F190F F250, F270, F280, F290, F304, F305, F309, F340, F350, F360, F370, F390, F400, F400LT, F403, F409, F420, F430, F450, F480, F480K, F490K, F520, F540, F540K, F560, F560K, F580, F580K, F590, F590K, F630, F660,

	F670, F680, F690, F701, F707, F709, FF709K, F801, F801A, F807, F807K, F808K, F809K, FR102, FR105, FR130, FX series, GRS series, GRX series, NV100, NV105, NV109M, NV170, NV190, NV200, NV209, NV309, NVR23, PG32, QR10, QR20, R500, R505CT, R505D, R505DT, R505J, R505T, R505TE, R505TEK, R505TS, R600HEK, R600HEP, R600HFPD, R600HMPD, R600MX, X18, X29, X9, XE17, XE7, XE7, XG18, XG19, XG28, XG28K, XG29, XG38, XG39, XG39K, XG500, XG700, XG9, Z505, Z505FA, Z505GAH, Z505GAM, Z505HE, Z505HS, Z505HSK, Z505JE, Z505JEK, Z505JS, Z505JSK, Z505LE, Z505LEK, Z505LS, Z505LSK, Z505R, Z505RX, Z505S, Z505SX, Z505SX, Z600HEK, Z600LEK, Z600NE, Z600NEK, Z600RE, Z600TEK
<b>S5</b>	<b>Toshiba</b> <b>Satellite:</b> 1110 series, 1115-S103, 1130 series, 1135-S125, 1905-S277, 1955-S801, 2430 series, 2435-S255
<b>S6</b>	<b>Qosimo:</b> E15-AV101, F15-AV201, F25-AV205